



DriTac - MCS 7000
Concrete Moisture Control System
Two-Part Epoxy

HELPFUL HINTS FOR MIXING & APPLYING

1. PREPARATION:

- a) HAVE ALL YOUR ROLLERS AND BRUSHES READY.
- b) COVER OR PROTECT BASEBOARDS, ADJACENT FLOORING, ETC.
- c) PROPERLY MIXED PRODUCT SHOULD BE A CONSISTENT GREEN WITH NO STREAKS OF BLUE OR YELLOW.
- d) KNOW WHERE YOU ARE GOING TO START AND HOW MUCH PRODUCT YOU WILL NEED.

2. PROPER COVERAGE:

- a) TO ENSURE PROPER COVERAGE MEASURE, MARK AND DIVIDE THE CONCRETE INTO SECTIONS.

3. LARGE AREAS:

- a) IN LARGE AREAS A TEAM EFFORT WORKS BEST. A MIXER, A CUT-IN PERSON AND AS MANY PEOPLE ON ROLLERS AS NEEDED.

4. MIXING AREA:

- a) SET UP A MIXING AREA THAT IS NOT PART OF THE FLOOR WHICH WILL BE COATED. GARAGE, PATIOS OR ADJACENT ROOMS WORK BEST. REMEMBER TO AVOID DRIPPING THE DriTac MCS 7000 ON AREAS THAT ARE NOT GOING TO BE COATED, SUCH AS SIDEWALKS, GARAGE FLOORS OR OTHER EXISTING FLOORS.

5. AFTER MIXING:

- a) AFTER MIXING, POUR OUT THE PRODUCT ONTO THE CONCRETE IN PUDDLES OR LINES APPROXIMATELY TWO FEET FROM ALL WALLS AND BEGIN ROLLING IMMEDIATELY.

6. CUT IN:

- a) CUT IN CORNERS, EDGES AND AROUND DOOR CASINGS WITH A 4" DISPOSABLE PAINT BRUSH.

7. CONCRETE MAY DARKEN:

- a) CONCRETE MAY DARKEN IN SOME AREAS, DEPENDING UPON THE POROSITY, BUT DO NOT ALLOW THIS TO SLOW YOU DOWN BY TRYING TO ELIMINATE THE DARK SPOTS.

8. DON'T MAKE A MASTERPIECE:

- a) DON'T MAKE A MASTERPIECE, THE OBJECT IS TO APPLY AN EVEN COAT. ACT AS IF YOU ARE PAINTING THE FLOOR.

9. CLEAN UP:

- a) REMOVE ALL ROLLER COVERS, CLEAN ROLLERS AND MIXING PADDLES IMMEDIATELY, USING MINERAL SPIRITS. TOOLS NOT CLEANED BECOME DISPOSABLE.

10. FLOORING INSTALLATION CURE TIME:

- a) FLOORING MAY BE INSTALLED OVER DriTac MCS 7000 AFTER 16 HOURS OF CURE TIME. IF THE FLOORING INSTALLATION IS DELAYED BEYOND 48 HOURS, THE DriTac CONCRETE MOISTURE CONTROL SYSTEM MUST BE LIGHTLY ABRADED USING A BUFFER. CLEAN THE ABRADED COATING THOROUGHLY BEFORE APPLYING THE ADHESIVE.

11. BLUSHING:

- a) BLUSHING MAY OCCUR IF THE AMBIENT TEMPERATURE OF THE COATED AREA IS NOT WITHIN LIMITATIONS. A THIN OILY RESIDUE, KNOWN AS BLUSHING, MAY DEVELOP ON THE SURFACE OF THE SEALER AFTER IT HAS CURED. THIS RESIDUE MUST BE REMOVED BY WIPING IT WITH A SOLVENT AND ALLOWING IT TO DRY PRIOR TO THE INSTALLATION.

12. STORAGE:

- a) STORE PRODUCT IN A HEATED AREA. COLD TEMPERATURES MAKE EPOXY DIFFICULT TO MIX AND SPREAD.